

## NOTICE

- FOR 68MM BOTTOM BRACKET, USE BLACK TUBE SPACER.
- FOR 73MM BOTTOM BRACKET, USE GOLD TUBE SPACER.
- IT IS VERY IMPORTANT THAT THE PROPER TUBE SPACER IS INSTALLED.
- IF YOU ARE USING A CHAIN TENSIONER DEVICE THAT MOUNTS BETWEEN THE BOTTOM BRACKET AND DRIVE SIDE CUP, YOU MUST ADD SPACERS TO THE APPROPRIATE TUBE BETWEEN THE BEARINGS. THE THICKNESS OF THE SPACERS MUST EQUAL THE WIDTH OF THE TENSIONER DEVICE YOU ARE INSTALLING. MOST TENSIONERS ARE 1/8" THICK. THEREFORE, YOU MUST ADD A 1/8" SPACER. FOR DIFFERENT SIZE TENSIONERS, ADD SPACERS ACCORDINGLY.
- THIS PROCEDURE MUST BE DONE IN ORDER FOR THE PROFILE RACING BOTTOM BRACKET TO FUNCTION CORRECTLY.

